



| Original | Replacement |
|--|---|
|  Mute |  Mute / Dimmer |
|  [<>] |  Picture / Format |
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  AV |  AV / Input / RDS |
|  0 |  0 |
|  Swap |  Back / Return |
|  Swap |  D.Menu / Top |
|  PC |  Fav / Marker / PC |

| Original | Replacement |
|--|---|
|  TV |  TV/Radio / |
|  Menu |  Menu / Home |
|  Text / Mix |  Text / Goto |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Down |  Down |
|  Vol+ |  Vol+ |
|  PR+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  PR- |  CH- / Page- |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  [i] |  Info / Angle |





| Original | Replacement |
|----------|-------------------|
| | Smart / List |
| | Zoom / Size |
| | Display / Media |
| | Eject / Surround |
| | Guide / EPG / -/- |
| | Subtitle / EQ |
| | Sound / Title |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

