


























Original		Replacement		Original		Replacement	
	Play		Play / Slow		8		8
	Pause		Pause / Step / Freeze		9		9
	CH-		CH- / Page-				
	CH+		CH+ / Page+				
	EQ		Subtitle / EQ				
	Vol-		Vol-				
	Vol+		Vol+				
	0		0				
	I<<		I<< / Preset-				
	>>I		>>I / Preset+				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

