










































































Original		Replacement		Original		Replacement	
	Power/ATT		Power		1		1
	Disp		Display / Media		2		2
	Up		CH+ / Page+		3		3
	I<</Down		I<< / Preset-		Setup		Setup / OPT /
	>>/Up		>>I / Preset+		Aspect		Picture / Format
	Down		CH- / Page-		Return		Back / Return
	<<		<< / Tune-		4		4
	>>		>> / Tune+		5		5
	Vol+		Vol+		6		6
	2nd Vol+		Shift + Vol+		Top M		D.Menu / Top
	Source		AV / Input / RDS		Up		Up
	Vol-		Vol-		Menu		Menu / Home
	2nd Vol-		Shift + Vol-		7		7
	Play		Play / Slow		8		8
	Pause		Pause / Step / Freeze		9		9
	Phone		Guide / EPG / -/--		Left		Left
	Band/Stop		Stop / Hold		Enter		OK





Original	Replacement	Original	Replacement
 Right	 Right		
 *	 Exit / Cancel / Clear		
 0	 0		
 #	 Fav / Marker / PC		
 OSD	 Smart / List		
 Down	 Down		
 Dual	 Audio / Lang I/II		
 Direct CLR	 TV/Radio /		
 Surround	 Eject / Surround		

