



Original	Replacement
	Power
	Display / Media
	D.Menu / Top
	Shift + 0
	Sleep / Timer
	AV / Input / RDS
	Sound / Title
	Picture / Format
	Zoom / Size
	1
	2
	3
	4
	5
	6
	7
	8

Original	Replacement
	9
	0
	Back / Return
	Info / Angle
	Pause / Step / Freeze
	Subtitle / EQ
	Audio / Lang I/II
	Vol+
	Vol-
	Mute / Dimmer
	CH+ / Page+
	CH- / Page-
	Up
	Down
	Right
	Left
	OK



