




















































	Original	Replacement		Original	Replacement
	OK		Ok		
	Power		Power		
	Back		Back		
	Home/Smart		Media		
	Up		Up		
	Down		Down		
	Left		Left		
	Right		Right		
	3D		3D		
	Mute		Mute		
	Ch+		Ch +		
	Ch-		Ch -		
	Vol+		Vol +		
	Vol-		Vol -		
	Wheel Up		2		
	Wheel Down		8		



































Original	Replacement
Power	 Power
Wheel Down	 Shift + Down
OK	 Ok
Up	 Up
Down	 Down
Wheel Up	 Shift + Up
Right	 Right
Left	 Left
Back	 Back
Home / Smart	 Smart
3D	 3D
123 / Q.Menu	 Shift + Ok
Vol +	 Vol +
Vol -	 Vol -
Mute	 Mute
P +	 Ch +
P -	 Ch -

Original	Replacement
Ratio	 Format
List	 List
Q.Menu	 Shift + Menu
Subtitle	 Subt
Settings	 Shift + Options
AD / PIP	 Dual
>>	 >>
>>>	 >>>
Play	 Play
<<<	 <<<
<<	 I<<
Rec	 Rec
Pause	 Pause
Stop / Live TV	 Stop
AV Mode	 Shift + AV
Text	 Text
FAV	 Shift + Pre Ch





Original	Replacement	Original	Replacement
Exit		Exit	Exit
TV / PC	 + 	Shift + Smart	Shift + Smart
Input		AV	AV
TV / Radio		TV/R	TV/R
Blue		Blue	Blue
Yellow		Yellow	Yellow
Green		Green	Green
Red		Red	Red
0		0	0
AD	 + 	Shift + Subt	Shift + Subt
Search	 + 	Shift + TV/R	Shift + TV/R
Live Menu		Menu	Menu
Recent		Pre Ch	Pre Ch
Live Zoom		Eject	Eject
App	 + 	Shift + Media	Shift + Media
Guide		Guide	Guide
Info		Info	Info

Original	Replacement	Original	Replacement
T.Opt		Options	Options
Q.View		D. Menu	D. Menu
Energy Saving	 + 	Shift + 3D	Shift + 3D
9		9	9
8		8	8
7		7	7
6		6	6
5		5	5
4		4	4
3		3	3
2		2	2
1		1	1
My APPS		Media	Media

