



| Original | Replacement | Original | Replacement |
|--------------|---|----------------|--|
| Power |  | Power | EQ SUBTITLE |
| OK |  | Subtitle | Subtitle / EQ |
| Up |  | Settings | Setup / OPT / |
| Down |  | >> | PRESET+ >>I / Preset+ |
| Right |  | >> | TUNE+ >> / Tune+ |
| Left |  | Play | SLOW Play / Slow |
| Back |  | AD / PIP | TITLE SOUND |
| Vol + |  | << | PRESET- I<< / Preset- |
| Vol - |  | << | TUNE- << / Tune- |
| Home / Smart |  | Rec | REC MODE Rec / Rec Mode |
| 3D |  +  Shift + 3 | Pause | STEP-FREEZE Pause / Step / Freeze |
| Mute |  | Text | GOTO TEXT Text / Goto |
| P + |  | FAV | PC FAV MARKER Fav / Marker / PC |
| P - |  | Exit | CLEAR EXIT Exit / Cancel / Clear |
| Ratio |  | Input | RDS AV INPUT AV / Input / RDS |
| List |  | Blue | Prime Video RANDOM Blue / Prime Video / Random |
| Q.Menu |  | Yellow | YouTube REPEAT A-B Yellow / YouTube / Repeat |
| | | Stop / Live TV | HOLD Stop / Hold |



| Original | Replacement | Original | Replacement |
|------------|------------------------------|---------------|--------------------------------|
| AV Mode | + Shift + AV / Input / RDS | 5 | 5 |
| Green | Green / APP / Repeat | Q.View | + Shift + Display / Media |
| Red | Red / Netflix / Search | 4 | 4 |
| 0 | 0 | Live Zoom | Zoom / Size |
| AD | Audio / Lang I/II | 3 | 3 |
| TV / PC | + Shift + Fav / Marker / PC | 2 | 2 |
| Search | + Shift + Red / Netflix / | 1 | 1 |
| App | + Shift + Green / APP / | T.Opt | + Shift + Setup / OPT / Tools |
| TV / Radio | TV/Radio / | Energy Saving | Eject / Surround |
| Guide | Guide / EPG / -/-- | My APPS | + Shift + Smart / List |
| Info | Info / Angle | | |
| Recent | Sleep / Timer | | |
| 9 | 9 | | |
| 8 | 8 | | |
| 7 | 7 | | |
| Live Menu | Display / Media | | |
| 6 | 6 | | |

