











































































































































Original	Replacement	Original	Replacement
	Power		Power
	[]		Subt
	Audio		Dual
	[■]/SV		TV/R
	V≡/LP		Pre Ch
	[≡I]/000		Guide
	Mute/Timer		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Pause		Pause
	T		Options
	M		Menu
	E		Exit
	i		Info
	Rec		Rec
	UP		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Stop		Stop
	<<		<<









































































Original		Replacement		Original		Replacement	
	Power		Power		OK		Ok
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		Red		Red
	6		6		Green		Green
	7		7		Yellow		Yellow
	8		8		Blue		Blue
	9		9		<<		<<
	0		0		Stop		Stop
	M		Menu		Play		Play
	E		Exit		>>		>>
	i		Info		Mute/Timer		Mute
	Rec		Rec		Audio		Dual
	Pause		Pause		[]		Subt
	T		Options		[■]/SV		TV/R





Original		Replacement		Original		Replacement	
	Power		Power		Green		Green
	1		1		Yellow		Yellow
	2		2		Blue		Blue
	3		3		<<		<<
	4		4		Stop		Stop
	5		5		Play		Play
	6		6		>>		>>
	7		7		Pause		Pause
	8		8		T		Options
	9		9		M		Menu
	0		0		E		Exit
	OK		Ok		Mute/Timer		Mute
	Up		Up		[≡I]/000		Guide
	Down		Down		V≡/LP		Pre Ch
	Right		Right		[■]/SV		TV/R
	Left		Left		Audio		Dual
	Red		Red		[]		Subt

