






















































| Original  | Replacement  |
|---|--|
|  Power               |  Power                          |
|  I<<                 |  I<< / Preset-                  |
|  Eject               |  Eject / Surround               |
|  <<                  |  << / Tune-                     |
|  >>                  |  >> / Tune+                     |
|  >>                  |  >>  / Preset+                  |
|  Play / Pause        |  Play / Slow                    |
|  Play / Pause        |  Pause / Step / Freeze          |
|  TV/TXT /            |  Setup / OPT /                  |
|  TV/TXT /            |  Shift + Goto Text / Text /     |
|  Cancel / Zoom      |  Shift + Exit / Cancel / Clear |
|  Reveal / Subtitle |  Shift + Subtitle / EQ        |
|  Stop              |  Stop / Hold                  |
|  Hold / Menu       |  Shift + Hold / Stop /        |
|  Hold / Menu       |  Shift + Home / Menu /        |
|  Size / Angle      |  Zoom / Size                  |
|  Subpage / Title   |  Shift + Sound / Title        |

| Original  | Replacement   |
|---|---|
|  Index / Goto    |  Info / Angle                |
|  Red / Program   |  Red / Netflix / Search      |
|  Green / Slow    |  Green / APP / Repeat        |
|  Yellow / Repeat |  Yellow / YouTube / Repeat   |
|  Blue / A-B      |  Blue / Prime Video / Random |
|  CH +            |  CH+ / Page+                 |
|  Sys-Menu        |  Menu / Home                 |
|  Vol +           |  Vol+                        |
|  CH -            |  CH- / Page-                 |
|  Input / Sourc   |  AV / Input / RDS            |
|  Vol -          |  Vol-                       |
|  DVD           |  Shift + 2                 |
|  DVD-Setup     |  D.Menu / Top              |
|  Up            |  Up                        |
|  Left          |  Left                      |
|  OK            |  OK                        |
|  Right         |  Right                     |





| Original  |          | Replacement   |                            | Original  |             | Replacement   |                           |
|---|----------|---|----------------------------|---|-------------|---|---------------------------|
|    | Down     |    | Down                       |    | Nicam / A2  |    | Audio / Lang I/II         |
|    | DVB      |    | Smart / List               |    | Mute        |    | Mute / Dimmer             |
|    | Sys-Exit |    | Exit / Cancel / Clear      |    | Sleep       |    | Sleep / Timer             |
|    | 1        |    | 1                          |    | TV / Radio  |    | TV/Radio /                |
|    | 2        |    | 2                          |    | FAV         |    | Fav / Marker / PC         |
|    | 3        |    | 3                          |    | Fav +       |    | Shift + CH+ /             |
|    | 4        |    | 4                          |    | Fav -       |    | Shift + CH- /             |
|    | 5        |    | 5                          |    | Pic. Format |    | Shift + Picture / Format  |
|    | 6        |    | 6                          |    | Subtitle    |    | Subtitle / EQ             |
|    | 7        |    | 7                          |    | Text        |    | Text / Goto               |
|  | 8        |  | 8                          |  | Display     |  | Display / Media           |
|  | 9        |  | 9                          |  | Language    |  | Shift + Audio / Lang I/II |
|  | -/--     |  | Shift + Guide / EPG / -/-- |  | EPG         |  | Guide / EPG / -/--        |
|  | 0        |  | 0                          |   |             |   |                           |
|  | Recall   |  | Back / Return              |   |             |   |                           |
|  | Picture  |  | Picture / Format           |   |             |   |                           |
|  | Sound    |  | Sound / Title              |   |             |   |                           |

