




| Original   | Replacement   |
|--|---|
|  Power    |  Power                         |
|  1        |  1                             |
|  2        |  2                             |
|  3        |  3                             |
|  4        |  4                             |
|  5        |  5                             |
|  6        |  6                             |
|  7        |  7                             |
|  8        |  8                             |
|  9        |  9                             |
|  FAV     |  Fav / Marker / PC            |
|  0      |  0                           |
|  TXT    |  Text / Goto                 |
|  Red    |  Red / Netflix / Search      |
|  Green  |  Green / APP / Repeat        |
|  Yellow |  Yellow / YouTube / Repeat   |
|  Blue   |  Blue / Prime Video / Random |

| Original   | Replacement   |
|--|---|
|  CEC      |  Smart / List          |
|  ?        |  D.Menu / Top          |
|  Exit     |  Exit / Cancel / Clear |
|  Menu     |  Menu / Home           |
|  Up       |  Up                    |
|  Back     |  Back / Return         |
|  Left     |  Left                  |
|  OK       |  OK                    |
|  Right    |  Right                 |
|  Down     |  Down                  |
|  Guide   |  Guide / EPG / -/-    |
|  Tools  |  Setup / OPT /       |
|  Vol+   |  Vol+                |
|  Source |  AV / Input / RDS    |
|  PR+    |  CH+ / Page+         |
|  Vol-   |  Vol-                |
|  Mute   |  Mute / Dimmer       |





|  | Original   | Replacement   | Original | Replacement |
|--|--|---|----------|-------------|
|  |  PR-        |  CH- / Page-           |          |             |
|  |  I<         |  I<< / Preset-         |          |             |
|  |  >I         |  >>I / Preset+         |          |             |
|  |  <<         |  << / Tune-            |          |             |
|  |  >>         |  >> / Tune+            |          |             |
|  |  Rec        |  Rec / Rec Mode        |          |             |
|  |  Play       |  Play / Slow           |          |             |
|  |  Pause      |  Pause / Step / Freeze |          |             |
|  |  Stop       |  Stop / Hold           |          |             |
|  |  [<>]      |  Picture / Format     |          |             |
|  |  Dialog   |  Audio / Lang I/II   |          |             |
|  |  [...]    |  Subtitle / EQ       |          |             |
|  |  Tv/Radio |  TV/Radio /          |          |             |
|  |  My Media |  Display / Media     |          |             |
|  |  |   |          |             |
|  |  |   |          |             |
|  |  |   |          |             |
|  |  |   |          |             |

