Original	Replacement	Original	Replacement
Muting	Mute / Dimmer	Volume+	Vol +
Power	Power	Menu	Menu / Home
Timer	Shift + Sleep / Timer	Up	Up
Clock Call	Setup / OPT /	Preset Memory	Smart / List
Sleep	Sleep / Timer	Treble	Sound / Title
TUNER	6	Left	Left
CD	3	Enter	OK
iPod	1	Right	Right
Line	2	Bass	Audio / Lang I/II
Bluetooth	9	Mode	Info / Angle
Stop	Stop / Hold	Down	Down
Play / Pause	Play / Slow	Clear	Exit / Cancel / Clear
<< / Tuning-	<< / Tune-	S.Bass	Subtitle / EQ
I<< / Preset-	I<< / Preset-	Dimmer	Shift + Mute / Dimmer
>>I / Preset+	>>I / Preset+	Shuffle	Blue / Prime Video / Random
>> / Tuning+	>> / Tune+	Repeat	Green / APP / Repeat
Volume-	Vol -	Playlist+	CH+ / Page+

Original	Replacement	Original	Replacement
Playlist-	CH- / Page-		
Display	Display / Media		