






























Original	Replacement	Original	Replacement
 Power	 Power	 Down / P -	 Ch -
 Mute	 Mute	 Right / Vol +	 Right
 1	 1	 Right / Vol +	 Vol +
 2	 2	 Left / Vol -	 Left
 3	 3	 Left / Vol -	 Vol -
 4	 4	 Menu	 Menu
 5	 5	 Menu	 Ok
 6	 6	 Text	 Text
 7	 7	 Text	 Exit
 8	 8	 Hold	 Stop
 9	 9	 ? / >>	 Dual
 0	 0	 -	 I<<
 PP	 Pre Ch	 +	 >>I
 Info	 Info	 ? / >>	 >>
 Up / P +	 Up	 Size	 Format
 Up / P +	 Ch +	 > / <>	 Play
 Down / P -	 Down		

