





Original	Replacement
	 Power
	 Mute
	 TV/R
	 Smart
	 Pre Ch
	 Text
	 D. Menu
	 3D
	 Media
	 Guide
	 Shift + Pause
	 Back
	 Shift + Up
	 <<
	 Play
	 >>
	 Rec

Original	Replacement
	 Pause
	 Stop
	 Red
	 Green
	 Yellow
	 Blue
	 List
	 Info
	 Up
	 Left
	 Ok
	 Right
	 Down
	 Menu
	 Exit
	 Vol +
	 Vol -



