


























Original	Replacement
	
Power	Power
	
Mute	Mute
	
Mosaico	List
	
DVR / Gravações	Media
	
VOD / Videoclube	Smart
	
Pesquisa	Shift + TV/R
	
Exit	Exit
	
Menu	Menu
	
i	Info
	
Vol +	Vol +
	
Vol -	Vol -
	
Up	Up
	
Left	Left
	
OK	Ok
	
Right	Right
	
Down	Down
	
P +	Ch +

Original	Replacement
	
P -	Ch -
	
Stop	Stop
	
<<	<<
	
Pause	Pause
	
Play	Play
	
>>	>>
	
Rec	Rec
	
Red	Red
	
Green	Green
	
Yellow	Yellow
	
Blue	Blue
	
I<<	I<<
	
Back	Back
	
Radio / TXT	TV/R
	
Radio / TXT	Text
	
>>I	>>I
	
1	1





Original	Replacement	Original	Replacement
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	GUIA /		Guide
	* / AV		AV
	# / -/--	 + 	Shift + Guide

