









































































































Original	Replacement	Original	Replacement
	[ ]→		EXIT Exit / Cancel / Clear
	Power		Power
	[1 2]		SHIFT + NETFLUX Shift + Red / Netflix /
	[← →]		SHIFT + APP Shift + Green / APP /
	[   >   <   ]		SHIFT + YouTube Shift + Yellow / YouTube /
	Red / Rec		REC MODE Rec / Rec Mode
	Red / Rec		NETFLUX Red / Netflix / Search
	Green / <<		APP Green / APP / Repeat
	Green / <<		TUNE- << / Tune-
	Yellow / Stop		HOLD Stop / Hold
	Yellow / Stop		YouTube Yellow / YouTube / Repeat
	Blue / Play		Prime Video Blue / Prime Video / Random
	Blue / Play		SLOW Play / Slow
	White / >>		TUNE+ >> / Tune+
	White / >>		PC FAV MARKER Fav / Marker / PC
	[   ]		SHIFT + GUIDE EPG Shift + Guide / EPG / -/-
	Up		Up
	[≡]		GOTO TEXT Text / Goto
	Left		Left
	OK		OK
	Right		Right
	[> <]		STEP-FREEZE Pause / Step / Freeze
	Down		Down
	[...]		EQ SUBTITLE Subtitle / EQ
	Vol+		VOL Vol+
	Mute		DIMMER MUTE Mute / Dimmer
	P+		CH+ CH+ / Page+
	Vol-		VOL Vol-
	P-		CH- CH- / Page-
	1		TV 1 1
	2		DVD 2 2
	3		CD-STB 3 3
	4		VIDEO 4 4
	5		TAPE 5 5









































































	Original	Replacement	Original	Replacement
	6	 6		
	7	 7		
	8	 8		
	9	 9		
	[i+]	 Info / Angle		
	0	 0		
	P<P / -/--	 Guide / EPG / -/--		
	[⊙]	 Sleep / Timer		
	[?]	 AV / Input / RDS		
	[↑↓] / Zoom	 Zoom / Size		
	Smart Sound	 Sound / Title		
	[ <> ]	 D.Menu / Top		
	Smart Picture	 Picture / Format		
	Instant Rec	 +  Shift + Rec / Rec Mode		
	I-II	 Audio / Lang I/II		
	DNR	 Back / Return		
	[ ]	 Setup / OPT /		

































































Original	Replacement	Original	Replacement
 DVD	 Shift + 2	 Vol+	 Vol+
 [1 2]	 Red / Netflix / Search	 Mute	 Mute / Dimmer
 [< >]	 Green / APP / Repeat	 P+	 CH+ / Page+
 [   >   <   ]	 Yellow / YouTube / Repeat	 Vol-	 Vol-
 <<	 << / Tune-	 P-	 CH- / Page-
 Stop	 Stop / Hold	 1	 1
 Play	 Play / Slow	 2	 2
 >>	 >> / Tune+	 3	 3
 [   ]	 Shift + Guide / EPG / -/-	 4	 4
 Up	 Up	 5	 5
 [≡]	 Text / Goto	 6	 6
 Left	 Left	 7	 7
 OK	 OK	 8	 8
 Right	 Right	 9	 9
 [> <]	 Pause / Step / Freeze	 [i+]	 Info / Angle
 Down	 Down	 0	 0
 [...]	 Subtitle / EQ	 P<P / -/-	 Guide / EPG / -/-










































Original	Replacement	Original	Replacement
 [ ]→	 Exit / Cancel / Clear	 [≡]	 Text / Goto
 Power	 Power	 Left	 Left
 [1 2]	 Shift + Red / Netflix /	 OK	 OK
 [← →]	 Shift + Green / APP /	 Right	 Right
 [   >   <   ]	 Shift + Yellow / YouTube /	 [ >   < ]	 Pause / Step / Freeze
 Red / Rec	 Red / Netflix / Search	 Down	 Down
 Red / Rec	 Rec / Rec Mode	 [...]	 Subtitle / EQ
 Green / <<	 Green / APP / Repeat	 Vol+	 Vol+
 Green / <<	 << / Tune-	 Mute	 Mute / Dimmer
 Yellow / Stop	 Stop / Hold	 P+	 CH+ / Page+
 Yellow / Stop	 Yellow / YouTube / Repeat	 Vol-	 Vol-
 Blue / Play	 Blue / Prime Video / Random	 P-	 CH- / Page-
 Blue / Play	 Play / Slow	 1	 1
 White / >>	 Fav / Marker / PC	 2	 2
 White / >>	 >> / Tune+	 3	 3
 [   ]	 Shift + Guide / EPG / -/-	 4	 4
 Up	 Up	 5	 5









































































	Original	Replacement	Original	Replacement
	6	 6		
	7	 7		
	8	 8		
	9	 9		
	[i+]	 Info / Angle		
	0	 0		
	P<P / -/--	 Guide / EPG / -/--		
	[⊙]	 Sleep / Timer		
	[?]	 AV / Input / RDS		
	[↑↓] / Zoom	 Zoom / Size		
	Smart Sound	 Sound / Title		
	[ <> ]	 D.Menu / Top		
	Smart Picture	 Picture / Format		
	Instant Rec	 +  Shift + Rec / Rec Mode		
	I-II	 Audio / Lang I/II		
	DNR	 Back / Return		
	[ ]	 Setup / OPT /		





























Original		Replacement		Original		Replacement	
	[ ]→		Exit / Cancel / Clear		Down		Down
	Power		Power		[...]		Subtitle / EQ
	[1 2]		Red / Netflix / Search		Vol+		Vol+
	[← →]		Green / APP / Repeat		Mute		Mute / Dimmer
	[   > < ]		Yellow / YouTube / Repeat		P+		CH+ / Page+
	Rec		Rec / Rec Mode		Vol-		Vol-
	<<		<< / Tune-		P-		CH- / Page-
	Stop		Stop / Hold		1		1
	Play		Play / Slow		2		2
	>>		>> / Tune+		3		3
	[   ]		Shift + Guide / EPG / -/-		4		4
	Up		Up		5		5
	[≡]		Text / Goto		6		6
	Left		Left		7		7
	OK		OK		8		8
	Right		Right		9		9
	[> <]		Pause / Step / Freeze		[i+]		Info / Angle





Original		Replacement		Original		Replacement	
	0		0				
	P<P / -/--		Guide / EPG / -/--				
	[⊙]		Sleep / Timer				
	[?]		AV / Input / RDS				
	[↕] / Zoom		Zoom / Size				
	Smart Sound		Sound / Title				
	[ <> ]		D.Menu / Top				
	Smart Picture		Picture / Format				
	Instant Rec		Shift + Rec / Rec Mode				
	I-II		Audio / Lang I/II				
	DNR		Back / Return				
	[ ]		Setup / OPT /				

