































































Original	Replacement
	 Power
	 Stop / Hold
	 Pause / Step / Freeze
	 Rec / Rec Mode
	 << / Tune-
	 Play / Slow
	 >> / Tune+
	 Zoom / Size
	 Fav / Marker / PC
	 Menu / Home
	 Guide / EPG / -/--
	 Shift + Smart / List
	 AV / Input / RDS
	 Smart / List
	 Shift + Menu / Home
	 Exit / Cancel / Clear
	 Red / Netflix / Search

Original	Replacement
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Info / Angle
	 Setup / OPT /
	 Back / Return
	 Picture / Format
	 Up
	 Down
	 Left
	 Right
	 OK
	 Vol+
	 Vol-
	 Shift + Red / Netflix /
	 Mute / Dimmer
	 CH+ / Page+





	Original	Replacement	Original	Replacement
	CH-	 CH PAGE -		
	1	 1		
	2	 2		
	3	 3		
	4	 4		
	5	 5		
	6	 6		
	7	 7		
	8	 8		
	9	 9		
	0	 0		
	Subtitle	 SUBTITLE		
	Text	 TEXT		

