











































































Original	Replacement	Original	Replacement
 Power	 Power	 Pause	 Pause / Step / Freeze
 Red	 Red / Netflix / Search	 I<	 I<< / Preset-
 Green	 Green / APP / Repeat	 Stop	 Stop / Hold
 Yellow	 Yellow / YouTube / Repeat	 Eject	 Eject / Surround
 Blue	 Blue / Prime Video / Random	 >I	 >>I / Preset+
 PopUp Menu/Disc Menu	 D.Menu / Top	 <<	 << / Tune-
 Home	 Menu / Home	 >>	 >> / Tune+
 Top Menu	 Picture / Format	 1	 1
 Up	 Up	 2	 2
 Left	 Left	 3	 3
 OK	 OK	 4	 4
 Right	 Right	 5	 5
 Down	 Down	 6	 6
 Back	 Back / Return	 7	 7
 :≡	 Smart / List	 8	 8
 :≡	 Setup / OPT /	 9	 9
 Play	 Play / Slow	 Subtitle	 Subtitle / EQ





Original	Replacement	Original	Replacement
 0	 0		
 Audio	 Audio / Lang I/II		

