



Original	Replacement
Power	Power
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
TTX/MIX	Text
PRE-CH	Pre Ch
Mute	Mute
CH List	List
Vol+	Vol +

Original	Replacement
Vol-	Vol -
CH+	Ch +
CH-	Ch -
Settings	Options
Home	Smart
Guide	Guide
Info	Info
Rec	Rec
Enter	Ok
Up	Up
Down	Down
Left	Left
Right	Right
Return	Back
Exit	Exit
Red	Red
Green	Green





Original		Replacement		Original		Replacement	
	Yellow		Yellow				
	Blue		Blue				
	Play		Play				
	Pause		Pause				
	<</ <<		<<				
	>>/>>		>>				
	Stop		Stop				
	AD/Subt.		Subt				
	Pic Size		Format				
	Picture	+	Shift + Format				

