






| Original | Replacement |
|---|---|
|  Power |  Power |
|  Text |  Text |
|  [≡?] |  Shift + D. Menu |
|  Subtitles |  Subt |
|  [≡] |  Shift + Format |
|  [≡o] |  3D |
|  Size |  Eject |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |

| Original | Replacement |
|--|--|
|  Recall |  Pre Ch |
|  Source |  AV |
|  DTV |  TV/R |
|  EPG |  Guide |
|  ESG |  Smart |
|  Radio |  Media |
|  Audio I / II |  Dual |
|  Mute |  Mute |
|  Vol + |  Vol + |
|  Vol - |  Vol - |
|  P + |  Ch + |
|  P - |  Ch - |
|  AV Mode |  Shift + AV |
|  Surround |  Shift + Dual |
|  DTV Menu |  Options |
|  DTV Menu |  D. Menu |
|  List |  List |





| Original | | Replacement | | Original | Replacement |
|---|--------------|---|--------|----------|-------------|
|  | Info |  | Info | | |
|  | Menu |  | Menu | | |
|  | Up |  | Up | | |
|  | Down |  | Down | | |
|  | Right |  | Right | | |
|  | Left |  | Left | | |
|  | OK |  | Ok | | |
|  | End |  | Exit | | |
|  | Return |  | Back | | |
|  | Red |  | Red | | |
|  | Green |  | Green | | |
|  | Yellow |  | Yellow | | |
|  | Blue |  | Blue | | |
|  | truD |  | Play | | |
|  | Sleep |  | Sleep | | |
|  | Video Format |  | Format | | |
|  | OPC |  | Pause | | |

