



Original	Replacement
Standby	Power
Subtitle	Subtitle / EQ
Audio	Audio / Lang I/II
Open/Close	Eject / Surround
Angle	Info / Angle
Title	Sound / Title
Vol+	Vol+
Prog	TV/Radio /
Menu	Menu / Home
Vol-	Vol-
Setup	Setup / OPT /
Up	Up
Play	Play / Slow
Pause	Pause / Step / Freeze
Left	Left
Enter	OK
Right	Right

Original	Replacement
Mute	Mute / Dimmer
Down	Down
Stop	Stop / Hold
1	1
2	2
3	3
Goto	Text / Goto
4	4
5	5
6	6
Clear	Exit / Cancel / Clear
7	7
8	8
9	9
0	0
<<	<< / Tune-
>>	>> / Tune+



