









































































































Original		Replacement		Original		Replacement	
	Power		Power		Info		Info
	3D		3D		P +		Ch +
	1		1		P -		Ch -
	2		2		W		Shift + Smart
	3		3		Smart TV		Smart
	4		4		@		Media
	5		5		Menu		Menu
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right / Zoom +		Right
	9		9		Left / Zoom -		Left
	0		0		OK		Ok
	ECO		Shift + 3D		Back		Back
	Source		AV		Exit		Exit
	Vol +		Vol +		Option		Options
	Vol -		Vol -		USB		Shift + Media
	Mute		Mute		TV		TV/R





Original		Replacement		Original		Replacement	
	Sleep		Sleep		Rec		Rec
	Guide		Guide		>>		>>
	FAV		Pre Ch				
	List		List				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		Dual				
	Subtitle		Subt				
	Text		Text				
	I<		I<<				
	Stop		Stop				
	Play / Pause		Play				
	Play / Pause		Pause				
	>I		>>I				
	<<		<<				

