











































































| Original  | Replacement | Original  | Replacement             |
|---|-------------|---|-------------------------|
|      | Power       |      | Power                   |
|      | 1           |      | 1                       |
|      | 2           |      | 2                       |
|      | 3           |      | 3                       |
|      | 4           |      | 4                       |
|      | 5           |      | 5                       |
|      | 6           |      | 6                       |
|      | 7           |      | 7                       |
|      | 8           |      | 8                       |
|      | 9           |      | 9                       |
|     | Recall      |     | Back / Return           |
|    | 0           |    | 0                       |
|    | SAT         |    | Shift + 0               |
|    | SAT         |    | AV / Input / RDS        |
|    | TV/Radio    |    | TV/Radio /              |
|    | Audio       |    | Audio / Lang I/II       |
|    | Subtitle    |    | Subtitle / EQ           |
|    | Text        |    | Text / Goto             |
|    | Live        |    | Display / Media         |
|    | VOD         |    | Smart / List            |
|    | Series      |    | Shift + Display / Media |
|    | WEB TV      |    | Shift + Smart / List    |
|    | Menu        |    | Menu / Home             |
|    | Up          |    | Up                      |
|    | Exit        |    | Exit / Cancel / Clear   |
|    | Left        |    | Left                    |
|    | OK          |    | OK                      |
|   | Right       |   | Right                   |
|  | EPG         |  | Guide / EPG / -/--      |
|  | Down        |  | Down                    |
|  | Info        |  | Info / Angle            |
|  | Vol+        |  | Vol+                    |
|  | Fav         |  | Fav / Marker / PC       |
|  | Page+       |  | CH+ / Page+             |





| Original  |             | Replacement   |                             |
|---|-------------|---|-----------------------------|
|    | Vol-        |    | Vol-                        |
|    | Mute        |    | Mute / Dimmer               |
|    | Page-       |    | CH- / Page-                 |
|    | Red / F1    |    | Red / Netflix / Search      |
|    | Green / F2  |    | Green / APP / Repeat        |
|    | Yellow / F3 |    | Yellow / YouTube / Repeat   |
|    | Blue / IPTV |    | Blue / Prime Video / Random |
|    | Option      |    | Setup / OPT /               |
|    | V-Format    |    | Picture / Format            |
|   | Resolution  |   | Zoom / Size                 |
|  | Sleep       |  | Sleep / Timer               |
|  | <<          |  | << / Tune-                  |
|  | >>          |  | >> / Tune+                  |
|  | I<<         |  | I<< / Preset-               |
|  | >>I         |  | >>I / Preset+               |
|  | Play        |  | Play / Slow                 |
|  | Pause       |  | Pause / Step / Freeze       |

| Original  |      | Replacement   |                |
|---|------|---|----------------|
|  | Stop |  | Stop / Hold    |
|  | Rec  |  | Rec / Rec Mode |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |
|   |      |   |                |

