






















































	Original	Rechange	Original	Rechange
	Standby	 Power		Search
	Menu	 Menu		Stop
	Title	 Options		Pause
	Setup	 Sleep		Repeat
	Up	 Up		Zoom
	Down	 Down		Slow
	Right	 Right		A-B
	Left	 Left		Vol+
	>>	 >>		Vol-
	<<	 <<		1
	>>	 >>		2
	<<	  <<		3
	Subtitle	 Subt		4
	Angle	 Guide		5
	Audio	 Dual		6
	Play	 Play		7
	Display	 Info		8



