





































































| Original | Rechange | Original | Rechange |
|--|---|--|--|
|  Power |  Power |  Play |  Play / Slow |
|  PBC |  Text / Goto |  Right |  Right |
|  Display |  Display / Media |  Slow |  Shift + Play / |
|  Eject |  Eject / Surround |  Down |  Down |
|  Subtitle |  Subtitle / EQ |  Stop |  Stop / Hold |
|  Search |  Red / Netflix / Search |  I<< |  I<< / Preset- |
|  Angle |  Info / Angle |  >>I |  >>I / Preset+ |
|  Language |  Audio / Lang I/II |  << |  << / Tune- |
|  Setup |  Setup / OPT / |  >> |  >> / Tune+ |
|  Title |  Sound / Title |  1/All |  Smart / List |
|  Menu |  Menu / Home |  A-B |  Yellow / YouTube / Repeat |
|  Zoom |  Zoom / Size |  Vol- |  Vol- |
|  Resume |  D.Menu / Top |  Vol+ |  Vol+ |
|  Up |  Up |  1 |  1 |
|  Pause |  Pause / Step / Freeze |  2 |  2 |
|  Left |  Left |  3 |  3 |
|  OK |  OK |  Mute |  Mute / Dimmer |



