



Original	Recharge	Original	Recharge
Standby	Shift + Power	Band	Smart / List
On	Power	Enter	OK
1	1	Menu	Menu / Home
2	2	A-Preset/A-Tune	Setup / OPT /
3	3	Channel/Control-	CH- / Page-
4	4	Shift	Back / Return
5	5	A/B	Red / Netflix / Search
6	6	C/D	Green / APP / Repeat
7	7	E/F	Yellow / YouTube / Repeat
8	8	G/H	Blue / Prime Video / Random
9	9	I/J	Fav / Marker / PC
10	Guide / EPG / -/--	T-Mode	Info / Angle
Dimmer	Mute / Dimmer	Sleep	Sleep / Timer
Display	Display / Media	Timer	Shift + Sleep / Timer
Tuning-	<< / Tune-	Memo	Text / Goto
Channel/Control+	CH+ / Page+		
Tuning+	>> / Tune+		

