



Original	Recharge	Original	Recharge
 Power	 Power	 Red	 Red
 TXT	 Text	 Green	 Green
 EPG	 Guide	 Yellow	 Yellow
 Input	 AV	 Blue	 Blue
 Menu	 Menu	 Vol+	 Vol +
 [>]	 Format	 Vol-	 Vol -
 Lang	 Dual	 Mute	 Mute
 Subt	 Subt	 [+]	 3D
 i	 Info	 P+	 Ch +
 EXIT	 Exit	 P-	 Ch -
 Q.Menu	 D. Menu	 1	 1
 Back	 Back	 2	 2
 Up	 Up	 3	 3
 Down	 Down	 4	 4
 Right	 Right	 5	 5
 Left	 Left	 6	 6
 OK	 Ok	 7	 7





Original		Recharge		Original		Recharge	
8 _{tuv}	8	8	8				
9 _{wxyz}	9	9	9				
0 ₋	0	0	0				
TV	TV	SEARCH TV/R	TV/R				
↔	↔	FAV PRE-CH	Pre Ch				

