



| Original | | Rechange | | Original | | Rechange | |
|---|------------|---|-------|---|------------|---|---------|
|  | Power |  | Power |  | >>I |  | >>I |
|  | Source |  | AV |  | << |  | << |
|  | Open/Close |  | Eject |  | >> |  | >> |
|  | Sleep |  | Sleep |  | Stop |  | Stop |
|  | 1 |  | 1 |  | Play |  | Play |
|  | 2 |  | 2 |  | Pause |  | Pause |
|  | 3 |  | 3 |  | Vol+ |  | Vol + |
|  | 4 |  | 4 |  | Vol- |  | Vol - |
|  | 5 |  | 5 |  | Mute |  | Mute |
|  | 6 |  | 6 |  | Repeat |  | Text |
|  | 7 |  | 7 |  | Tuning+ |  | Ch + |
|  | 8 |  | 8 |  | Tuning- |  | Ch - |
|  | 9 |  | 9 |  | Disc Menu |  | D. Menu |
|  | 0 |  | 0 |  | Menu |  | Menu |
|  | Dolby PL |  | Dual |  | Title Menu |  | TV/R |
|  | DSP/EQ |  | Guide |  | Tools |  | Options |
|  | I<< |  | I<< |  | Info |  | Info |





| Original | | Rechange | | Original | | Rechange | |
|----------|----------------------|----------|--------|----------|--|----------|--|
| | Return | | Back | | | | |
| | Exit | | Exit | | | | |
| | Up | | Up | | | | |
| | Down | | Down | | | | |
| | Right | | Right | | | | |
| | Left | | Left | | | | |
| | Enter | | Ok | | | | |
| | Red | | Red | | | | |
| | Green/Tuner | | Green | | | | |
| | Yellow/MO/ST | | Yellow | | | | |
| | Blue/CD Ripping | | Blue | | | | |
| | Dimmer | | Subt | | | | |
| | S.Vol | | Format | | | | |
| | P.Bass/Audio Upscale | | 3D | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |





| | Original | Recharge | | Original | Recharge |
|---|-------------|---|-------|---|----------|
|  | Power |  | Power |  | Pause |
|  | Function Tv |  | AV |  | Vol + |
|  | Sleep |  | Sleep |  | Vol - |
|  | 1 |  | 1 |  | Mute |
|  | 2 |  | 2 |  | CH+ |
|  | 3 |  | 3 |  | CH- |
|  | 4 |  | 4 |  | Menu |
|  | 5 |  | 5 |  | Tools |
|  | 6 |  | 6 |  | Info |
|  | 7 |  | 7 |  | Return |
|  | 8 |  | 8 |  | Exit |
|  | 9 |  | 9 |  | Up |
|  | 0 |  | 0 |  | Down |
|  | << |  | << |  | Right |
|  | >> |  | >> |  | Left |
|  | Stop |  | Stop |  | Enter |
|  | Play |  | Play |  | Red |



