





































































| Original   | Recharge  |
|--|---|
|  Power    |  Power                       |
|  Red      |  Red / Netflix / Search      |
|  Green    |  Green / APP / Repeat        |
|  Yellow   |  Yellow / YouTube / Repeat   |
|  Blue     |  Blue / Prime Video / Random |
|  TV/SAT   |  AV / Input / RDS            |
|  TV/Radio |  TV/Radio /                  |
|  Zoom     |  Zoom / Size                 |
|  List     |  Smart / List                |
|  Audio    |  Audio / Lang I/II           |
|  EPG     |  Guide / EPG / -/--         |
|  Timer  |  Sleep / Timer             |
|  Text   |  Text / Goto               |
|  Exit   |  Exit / Cancel / Clear     |
|  Menu   |  Menu / Home               |
|  M/P    |  Display / Media           |
|  Mute   |  Mute / Dimmer             |

| Original   | Recharge  |
|--|---|
|  CH+    |  CH+ / Page+         |
|  CH-    |  CH- / Page-         |
|  Up     |  Up                  |
|  Down   |  Down                |
|  Right  |  Right               |
|  Left   |  Left                |
|  OK     |  OK                  |
|  Vol+   |  Vol+                |
|  Vol-   |  Vol-                |
|  Recall |  Back / Return       |
|  P+    |  >>  / Preset+      |
|  P-   |   << / Preset-     |
|  FAV  |  Fav / Marker / PC |
|  1    |  1                 |
|  2    |  2                 |
|  3    |  3                 |
|  4    |  4                 |






















| Original | Rechange          |
|----------|-------------------|
| Power    | Power             |
| SAT      | Smart / List      |
| Info     | Info / Angle      |
| 1        | 1                 |
| 2        | 2                 |
| 3        | 3                 |
| 4        | 4                 |
| 5        | 5                 |
| 6        | 6                 |
| 7        | 7                 |
| 8        | 8                 |
| 9        | 9                 |
| 0 / Zoom | Zoom / Size       |
| 0 / Zoom | 0                 |
| Audio    | Audio / Lang I/II |
| Mute     | Mute / Dimmer     |
| Recall   | Back / Return     |



















| Original     | Rechange                    |
|--------------|-----------------------------|
| FAV          | Fav / Marker / PC           |
| Up / CH+     | CH+ / Page+                 |
| Down / CH-   | Down                        |
| Up / CH+     | Up                          |
| Right / Vol+ | Right                       |
| Right / Vol+ | Vol+                        |
| Down / CH-   | CH- / Page-                 |
| Left / Vol-  | Vol-                        |
| Left / Vol-  | Left                        |
| OK           | OK                          |
| Menu         | Menu / Home                 |
| Exit         | Exit / Cancel / Clear       |
| Blue / Pause | Blue / Prime Video / Random |
| Blue / Pause | Pause / Step / Freeze       |
| Red / Text   | Red / Netflix / Search      |
| Red / Text   | Text / Goto                 |
| Multivideo   | Display / Media             |














| Original   | Rechange  |                       |
|------------|---|-----------------------|
| Mute       |    | Mute / Dimmer         |
| PWR On/Off |    | Power                 |
| App        |  +  | Shift + Green / APP / |
| Epg        |    | Guide / EPG / -/--    |
| Info       |    | Info / Angle          |
| Subt.List  |    | Subtitle / EQ         |
| TV         |    | TV/Radio /            |
| Text       |    | Text / Goto           |
| Zoom       |    | Zoom / Size           |
| Menu       |    | Menu / Home           |
| TV/SAT     |    | AV / Input / RDS      |
| Menu Up    |   | Up                    |
| Display    |    | Display / Media       |
| Menu Left  |    | Left                  |
| OK Enter   |    | OK                    |
| Menu Right |    | Right                 |
| Exit       |    | Exit / Cancel / Clear |


















| Original     | Rechange  |                            |
|--------------|---|----------------------------|
| Menu Down    |    | Down                       |
| Back         |    | Back / Return              |
| Volume+      |    | Vol+                       |
| CH/Page+     |    | CH+ / Page+                |
| Volume-      |    | Vol-                       |
| CH/Page-     |    | CH- / Page-                |
| Audio        |    | Audio / Lang I/II          |
| 1. ?         |    | 1                          |
| 2abc         |    | 2                          |
| 3def         |    | 3                          |
| 4ghi         |    | 4                          |
| 5jkl         |   | 5                          |
| 6mno         |    | 6                          |
| 7pqrm        |    | 7                          |
| 8tuv         |    | 8                          |
| 9wxyz        |    | 9                          |
| Guide Pilote |  +  | Shift + Guide / EPG / -/-- |







| Original | Recharge  | Original              | Recharge              |
|----------|---|-----------------------|-----------------------|
| Power    |    | Power                 | Power                 |
| Mute     |    | Mute / Dimmer         | Mute / Dimmer         |
| Pause    |    | Pause / Step / Freeze | Pause / Step / Freeze |
| Audio    |    | Audio / Lang I/II     | Audio / Lang I/II     |
| Zoom     |    | Zoom / Size           | Zoom / Size           |
| Timer    |    | Sleep / Timer         | Sleep / Timer         |
| Tv/Radio |    | TV/Radio /            | TV/Radio /            |
| Text     |    | Text / Goto           | Text / Goto           |
| Tv/SAT   |    | AV / Input / RDS      | AV / Input / RDS      |
| Menu     |    | Menu / Home           | Menu / Home           |
| Up/CH+   |   | Up                    | Up                    |
| Info     |  | Info / Angle          | Info / Angle          |
| Left     |  | Left                  | Left                  |
| OK       |  | OK                    | OK                    |
| Right    |  | Right                 | Right                 |
| Exit     |  | Exit / Cancel / Clear | Exit / Cancel / Clear |
| Down/CH- |  | Down                  | Down                  |

| Original | Recharge  | Original          | Recharge          |
|----------|---|-------------------|-------------------|
| Recall   |    | Back / Return     | Back / Return     |
| Vol+     |    | Vol+              | Vol+              |
| List     |    | Smart / List      | Smart / List      |
| P+       |    | CH+ / Page+       | CH+ / Page+       |
| Vol-     |    | Vol-              | Vol-              |
| M/P      |    | Display / Media   | Display / Media   |
| P-       |    | CH- / Page-       | CH- / Page-       |
| 1        |    | 1                 | 1                 |
| 2        |    | 2                 | 2                 |
| 3        |    | 3                 | 3                 |
| 4        |   | 4                 | 4                 |
| 5        |  | 5                 | 5                 |
| 6        |  | 6                 | 6                 |
| 7        |  | 7                 | 7                 |
| 8        |  | 8                 | 8                 |
| 9        |  | 9                 | 9                 |
| EPG      |  | Guide / EPG / -/- | Guide / EPG / -/- |



