







































































Original		Recharge		Original		Recharge	
	Power		Power		Mute		Mute
	Netflix		Media		[i]		Info
	TV		TV/R		P+		Ch +
	1		1		P-		Ch -
	2		2		*		Menu
	3		3		Home		Smart
	4		4		Guide		Guide
	5		5		≡		Options
	6		6		Back		Back
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Eco		3D		OK		Ok
	Source		AV		Exit		Exit
	Vol+		Vol +		Zoom+		Shift + Ch +
	Vol-		Vol -		Zoom-		Shift + Ch -





Original		Recharge		Original		Recharge	
	List		List		Pause		Pause
	Sleep		Sleep		>>		>>
	PRE-CH		Pre Ch				
	FAV		Shift + Pre Ch				
	Rec		Rec				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		Dual				
	Subtitle		Subt				
	Text		Text				
	I<		I<<				
	Stop		Stop				
	Play		Play				
	>I		>>I				
	<<		<<				

