







































































	Original	Rechange	Original	Rechange
	1		1	1
	2		2	2
	3		3	3
	4		4	4
	5		5	5
	6		6	6
	7		7	7
	8		8	8
	9		9	9
	0		0	0
	Zoom		Eject	
	Menu		Menu	
	Audio		Dual	
	Subtitle		Subt	
	Title		Info	
	Mode		Pre Ch	
	Setup		Options	
	A-B		3D	
	Angle		Smart	
	Repeat		Text	
	OSD		Media	
	Return		Back	
	Enter		Ok	
	Vol-		Vol -	
	Vol+		Vol +	
	Mute		Mute	
	Stop		Stop	
	Play		Play	
	Pause		Pause	
	<<		<<	
	>>		>>	
	<<		Left	
	>>		Right	
	I<<		I<<	



