







































































Original		Rechange		Original		Rechange	
	Power		Power		Left		Left
	Mute		Mute / Dimmer		Enter		OK
	1		1		Right		Right
	2		2		Menu		Menu / Home
	3		3		Down		Down
	4		4		Exit		Exit / Cancel / Clear
	5		5		Vol +		Vol+
	6		6		List		Smart / List
	7		7		CH +		CH+ / Page+
	8		8		Vol -		Vol-
	9		9		CH -		CH- / Page-
	Source		AV / Input / RDS		Fav		Fav / Marker / PC
	0		0		Sleep		Sleep / Timer
	Info		Info / Angle		Index		Display / Media
	DMP		D.Menu / Top		Recall		Back / Return
	Up		Up		Red / <<		Red / Netflix / Search
	EPG		Guide / EPG / -/-		Red / <<		<< / Tune-









































































	Original	Rechange	Original	Rechange
	Green / >>	 >> / Tune+		
	Green / >>	 Green / APP / Repeat		
	Yellow / I<<	 I<< / Preset-		
	Yellow / I<<	 Yellow / YouTube / Repeat		
	Blue / >>	 Blue / Prime Video / Random		
	Blue / >>	 >> / Preset+		
	Text / Play/Pause	 Text / Goto		
	Text / Play/Pause	 Pause / Step / Freeze		
	Text / Play/Pause	 Play / Slow		
	Stop / Still	 Stop / Hold		
	Timer / Subtitle	 Subtitle / EQ		
	Size / Aspect	 Zoom / Size		
	Cancel [≡X]	 Shift + Exit / Cancel / Clear		
	Radio	 TV/Radio /		
	Audio / I/II	 Audio / Lang I/II		
	Rec	 Rec / Rec Mode		





Original		Rechange		Original		Rechange	
	Power		Power		Left		Left
	Mute		Mute / Dimmer		Enter		OK
	1		1		Right		Right
	2		2		Menu		Menu / Home
	3		3		Down		Down
	4		4		Exit		Exit / Cancel / Clear
	5		5		Vol+		Vol+
	6		6		List		Smart / List
	7		7		CH+		CH+ / Page+
	8		8		Vol-		Vol-
	9		9		CH-		CH- / Page-
	[≡?]/Source		AV / Input / RDS		♥		Fav / Marker / PC
	0		0		Sleep		Sleep / Timer
	[≡i]/Info		Info / Angle		Index		Display / Media
	DMP		D.Menu / Top		Back		Back / Return
	Up		Up		Red		Red / Netflix / Search
	EPG		Guide / EPG / -/--		<<		<< / Tune-





Original	Recharge	Original	Recharge
 Green	 Green / APP / Repeat		
 >>	 >> / Tune+		
 Yellow	 Yellow / YouTube / Repeat		
 I<<	 I<< / Preset-		
 Blue	 Blue / Prime Video / Random		
 >>	 >> / Preset+		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 [=]	 Text / Goto		
 Stop/Still	 Stop / Hold		
 [=+]	 Picture / Format		
 [=o]/Subtitle	 Subtitle / EQ		
 [=◇]/[+]	 Zoom / Size		
 [=x]	 Setup / OPT /		
 Radio	 TV/Radio /		
 Audio	 Audio / Lang I/II		
 Rec	 Rec / Rec Mode		

