

































































Original	Recharge	Original	Recharge
	Power		Power
	SAT		AV
	Mute		Mute
	PGUP		Shift + Ch +
	PGDN		Shift + Ch -
	FAV +		Shift + Right
	FAV -		Shift + Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SUB		Subt
	Audio		Dual
	TV / R		TV/R
	Sleep		Sleep
	TXT		Text
	RCL		Back
	Menu		Menu
	Info		Info
	VL +		Vol +
	VL -		Vol -
	Up		Up
	Right		Right
	Down		Down





Original	Rechange
	
Left	Left
	
OK	Ok
	
CH +	Ch +
	
CH -	Ch -
	
EPG	Guide
	
FAV	Pre Ch
	
<<	<<
	
>>	>>
	
Pause	Pause
	
I<<	I<<
	
>>I	>>I
	
Rec	Rec
	
Play / Pause	Play
	
Stop	Stop
	
USB	Media
	
MP3	Smart
	
JPEG	Shift + Media

Original	Rechange
	
PVR List	List
	
Still >I<	Shift + Stop
	
Zoom	Eject
	
Edit	Options
	
Exit	Exit
	
A-B	Shift + Text
	
T.S.	3D
	
GOTO	D. Menu

