






























































































Original		Rechange		Original		Rechange	
	Power		Power		Vol -		Vol -
	Mute		Mute		Up		Up
	DVB / Analogue		TV/R		Right		Right
	AV		AV		Down		Down
	Multimedia		Media		Left		Left
	1		1		OK / Select		Ok
	2		2		PR/Page +		Ch +
	3		3		PR/Page -		Ch -
	4		4		S.Effect		Pre Ch
	5		5		Guide		Guide
	6		6		Subtitle		Subt
	7		7		Edit		Shift + Pre Ch
	8		8		Sleep		Sleep
	9		9		Still		Stop
	0		0		Menu		Menu
	Audio / I/II		Dual		Aspect		Format
	Vol +		Vol +		Normal		Smart





Original		Rechange		Original		Rechange	
	i / Recall		Back				
	Cancel / Exit		Exit				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text		Text				
	Reveal		Options				
	T.Cancel		Shift + Exit				
	Size		Eject				
	Subcode		Shift + Subt				
	Hold		Pause				
	Index		Info				

