





























































| Original   | Recharge   |
|--|--|
|  Power        |  Power  |
|  Sleep        |  Sleep  |
|  TV / AV      |  AV     |
|  TV           |  Red    |
|  VCR / AUX    |  Green  |
|  Tuner / Band |  Yellow |
|  DVD / CD     |  Blue   |
|  1            |  1      |
|  2            |  2      |
|  3            |  3      |
|  4           |  4     |
|  5          |  5    |
|  6          |  6    |
|  7          |  7    |
|  8          |  8    |
|  9          |  9    |
|  0          |  0    |

| Original  | Recharge   |
|---|--|
|  Mute / 10                     |  Guide          |
|  Cancel                        |  Exit           |
|  CH +                          |  Ch +           |
|  CH -                          |  Ch -           |
|  Volume +                      |  Vol +          |
|  Volume -                      |  Vol -          |
|  I<< Skip                      |  I<<            |
|  >>I Skip                      |  >>I            |
|  << Slow/Search                |  <<             |
|  >> Slow/Search                |  >>             |
|  Stop                         |  Stop          |
|  Pause                       |  Pause        |
|  Play                        |  Play         |
|  Top Menu / Direct Navigator |  Shift + Menu |
|  Top Menu / Direct Navigator |  List         |
|  Menu / Play List            |  Menu         |
|  Up                          |  Up           |





| Original  |                    | Rechange  |                 | Original  |              | Rechange  |                |
|---|--------------------|---|-----------------|---|--------------|---|----------------|
|    | Left               |    | Left            |    | Zoom         |    | Eject          |
|    | Enter              |    | Ok              |    | Muting       |    | Mute           |
|    | Right              |    | Right           |    | Setup        |    | Options        |
|    | Down               |    | Down            |    | FL Display   |    | Shift + Info   |
|    | Display / TV Vol - |    | Info            |    | Group        |    | TV/R           |
|    | Display / TV Vol - |    | Shift + Left    |    | Page         |    | Shift + TV/R   |
|    | Return / TV Vol +  |    | Back            |    | Repeat       |    | Text           |
|    | Return / TV Vol +  |    | Shift + Right   |    | Play Mode    |    | Shift + Play   |
|    | Subwoofer          |    | Shift + Dual    |    | CH Select    |    | Smart          |
|    | Super SRND.        |    | Shift + Options |    | Test         |    | Shift + Pre Ch |
|   | SFC                |   | D. Menu         |   | Quick Replay |   | Media          |
|  | C.Focus            |  | 3D              |  | Subtitle     |  | Subt           |
|  | Dolby PL II        |  | Format          |   |              |   |                |
|  | Mix 2CH            |  | Shift + Format  |   |              |   |                |
|  | C.S.M              |  | Shift + Subt    |   |              |   |                |
|  | Position           |  | Pre Ch          |   |              |   |                |
|  | Audio              |  | Dual            |   |              |   |                |

