

































































Original		Rechange		Original		Rechange	
	Power		Power		Language		Dual
	Mute		Mute		Favourite		Pre Ch
	DVB / Analog		TV/R		Cancel / Exit		Exit
	Multi Media		Media		Menu		Menu
	AV		AV		Aspect		Format
	Normal		Smart		Audio I / II		Shift + Dual
	Vol +		Vol +		Recall		Back
	Vol -		Vol -		S.Effect		Options
	PR/Page +		Ch +		1		1
	PR/Page -		Ch -		2		2
	Up		Up		3		3
	Left		Left		4		4
	OK / Select		Ok		5		5
	Right		Right		6		6
	Down		Down		7		7
	Guide		Guide		8		8
	Subtitle		Subt		9		9



