






































































| Original | Recharge | Original | Recharge |
|---|--|---|--|
|  Power |  Power |  Blue / Subtitle |  Blue |
|  DVB |  Media |  Blue / Subtitle |  Subt |
|  Prog+ |  Shift + Ch + |  CH+ |  Ch + |
|  Prog- |  Shift + Ch - |  CH- |  Ch - |
|  System |  Smart |  Vol+ |  Vol + |
|  Nicam/A2 |  List |  Vol- |  Vol - |
|  DVB Menu |  D. Menu |  TV-Menu |  Menu |
|  TV Format |  Format |  TV-Exit |  Exit |
|  Exit |  Shift + Exit |  Up |  Up |
|  Info |  Info |  Left |  Left |
|  Language |  Dual |  OK |  Ok |
|  Text |  Shift + Text |  Right |  Right |
|  FAV |  Pre Ch |  Down |  Down |
|  EPG |  Guide |  TV/AV |  AV |
|  Red / TV/Radio |  Red |  Display |  Shift + Info |
|  Green / Audio |  Green |  1 |  1 |
|  Yellow / Freeze |  Yellow |  2 |  2 |



