



Original	Recharge
Power On	Power
Power Off	Shift + Power
Mute	Mute
Cable/Sat	Shift + 1
STB	Shift + 2
TV	Shift + 3
Disc	Shift + 4
Server	Shift + 5
AUX	Shift + 6
Audio	Shift + 7
Game	Shift + 8
AVR	Red
USB	Green
Network	Yellow
Radio	Blue
Surr.Mode	Smart
OSD Menu	Menu

Original	Recharge
Up	Up
Left	Left
OK	Ok
Right	Right
Down	Down
Back/Exit	Back
Info/Option	Info
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0





Original	Recharge
Clear	Exit
Test	Text
Vol+	Vol +
Vol-	Vol -
CH/Tuner Up	Ch +
CH/Tuner Down	Ch -
Delay	Options
Sleep	Sleep
Tone	Subt
Dim	Media
P-Scan	Dual
Direct	AV
Mem	Format
RDS	List
I<	I<<
<<	<<<
>>	>>>

Original	Recharge
>	>>
Top Menu	D. Menu
Stop	Stop
Play	Play
Pause	Pause
Prev.CH	Pre Ch

