






















































	Original	Recharge		Original	Recharge
	Power		Power		Green
	[≡]		Text		Yellow
	Sleep		Sleep		Blue
	[i+]		Info		Vol +
	[...]		Subt		Vol -
	[≡+]		3D		Ch +
	[≡o]		Options		Ch -
	[≡?]		Guide		Mute
	Return		Shift + Back		1
	Up		Up		2
	Left		Left		3
	OK		Ok		4
	Right		Right		5
	Down		Down		6
	End		Exit		7
	Menu		Menu		8
	Red		Red		9



