



	Original	Rechange	Original	Rechange
	Power			Right
	Time			Down
	Display			I<< Prev
	Open / Close			>>I Next
	Angle			<< FR
	Language			>> FF
	Sub.Title			Zoom
	Title			Setup
	Menu / PBC			L / R
	P / N			Repeat
	Return			Mark
	Mute			Goto
	Play			Pause / Step
	Stop			Slow
	Up			1
	Left			2
	Enter			3



