





























| Original  | Recharge  | Original   | Recharge  |
|---|---|--|---|
|  Standby / On            |  Power                 |  Repeat / Shuffle |  Green / APP / Repeat  |
|  Sleep                   |  Sleep / Timer         |  Memory           |  Smart / List          |
|  Timer                   |  Shift + Sleep / Timer |  Clear            |  Exit / Cancel / Clear |
|  Dimmer                  |  Shift + Mute / Dimmer |  Mode             |  Picture / Format      |
|  Input Sel. CD           |  3                     |  i / Now Playing  |  Info / Angle          |
|  Input Sel. Bluetooth    |  9                     |  Left             |  Left                  |
|  Input Sel.              |  Fav / Marker / PC     |  Up               |  Up                    |
|  Input Sel. Tuner        |  6                     |  Enter            |  OK                    |
|  Input Sel. USB          |  8                     |  Right            |  Right                 |
|  Input Sel. Line Digital |  2                     |  Setup            |  Setup / OPT /         |
|  I<< / Preset-           |  I<< / Preset-         |  Down             |  Down                  |
|  Play / Pause            |  Pause / Step / Freeze |  Return           |  Back / Return         |
|  Play / Pause          |  Play / Slow         |  Volume+        |  Vol+                |
|  >>I / Preset+         |  >>I / Preset+       |  Sound          |  Sound / Title       |
|  << / Tune-            |  << / Tune-          |  Volume-        |  Vol-                |
|  Stop                  |  Stop / Hold         |  Mute           |  Mute / Dimmer       |
|  >> / Tune+            |  >> / Tune+          |  |   |

