



Original	Recharge
Power	Power
Eco/Energy	3D
AV Mode	Shift + AV
Input	AV
Tv/Rad	TV/R
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List
Q.View	Eject

Original	Recharge
FAV/Mark/Char/Nu	Pre Ch
Ratio	Format
Mute/Delete	Mute
P+	Ch +
P-	Ch -
Vol+	Vol +
Vol-	Vol -
Premium	Smart
Q.Menu	D. Menu
Home	Menu
Back	Back
Guide	Guide
Exit	Exit
OK	Ok
Up	Up
Down	Down
Right	Right



