







































































Original		Recharge		Original		Recharge	
	Power		Power		Left		Left
	Mute		Mute		OK		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		FAV		Pre Ch
	4		4		EPG		Guide
	5		5		V+		Vol +
	6		6		V-		Vol -
	7		7		Info		Info
	8		8		Audio		Dual
	9		9		Text		Text
	0		0		P+		Ch +
	SAT		Smart		P-		Ch -
	Tv/R		TV/R		Red		Red
	Menu		Menu		RCL		Options
	Exit		Exit		Green/Pause		Green
	Up		Up		Yellow		Yellow





Original		Recharge		Original		Recharge	
	SUB		Subt				
	V.F		3D				
	Blue		Blue				
	Pause		Pause				
	<		I<<				
	>		>>I				
	Rec		Rec				
	Play		Play				
	<<		<<				
	>>		>>				
	Stop		Stop				





Original	Recharge
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Smart
 Tv/R	 TV/R
 Menu	 Menu
 Exit	 Exit
 Up	 Up

Original	Recharge
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 FAV	 Pre Ch
 EPG	 Guide
 V+	 Vol +
 V-	 Vol -
 Info	 Info
 Audio	 Dual
 Text	 Text
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 RCL	 Options
 Green/Pause	 Green
 Yellow	 Yellow








Original		Recharge		Original		Recharge	
	SUB		Subt				
	V.F		3D				
	Blue		Blue				
	Pause		Pause				
	<		I<<				
	>		>>I				
	Rec		Rec				
	Play		Play				
	<<		<<				
	>>		>>				
	Stop		Stop				



























Original	Recharge
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Smart
 Tv/R	 TV/R
 Menu	 Menu
 Exit	 Exit
 Up	 Up

Original	Recharge
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 FAV	 Pre Ch
 EPG	 Guide
 V+	 Vol +
 V-	 Vol -
 Info	 Info
 Audio	 Dual
 Text	 Text
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 RCL	 Options
 Green/Pause	 Green
 Yellow	 Yellow





Original		Rechange		Original		Rechange	
	SUB		Subt				
	V.F		3D				
	Blue		Blue				
	Pause		Pause				
	<		I<<				
	>		>>I				
	Rec		Rec				
	Play		Play				
	<<		<<				
	>>		>>				
	Stop		Stop				

