







































































Original		Recharge		Original		Recharge	
	Power		Power		Left		Left
	Mute		Mute / Dimmer		OK		OK
	1		1		Right		Right
	2		2		Down		Down
	3		3		Back		Back / Return
	4		4		Menu		Menu / Home
	5		5		NETFLIX		Shift + Red / Netflix /
	6		6		YouTube		Shift + Yellow / YouTube /
	7		7		prime video		Shift + Blue / Prime
	8		8		Google Play		Shift + Green / APP /
	9		9		Vol+		Vol+
	Info		Info / Angle		Google Assistant		Smart / List
	0		0		P+		CH+ / Page+
	EPG		Guide / EPG / -/--		Vol-		Vol-
	Settings		Setup / OPT /		Home		D.Menu / Top
	Input		AV / Input / RDS		Home		Display / Media
	Up		Up		P-		CH- / Page-





Original		Recharge		Original		Recharge	
	Text		Text / Goto				
	USB	 + 	Shift + 8				
	I/II		Audio / Lang I/II				
	Subt		Subtitle / EQ				
	Play / Text Mix		Play / Slow				
	Pause		Pause / Step / Freeze				
	Stop / Text Hold		Stop / Hold				
	Text Size		Zoom / Size				
	<< / Text		<< / Tune-				
	I<< / Text Index		I<< / Preset-				
	>>I / Text Reveal		>>I / Preset+				
	>> / Text Cancel		>> / Tune+				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				

