






















































	Original	Recharge		Original	Recharge
	Power		Power		Info
	Sleep		Sleep		AV
	Mute		Mute		Up
	1		1		Ch +
	2		2		Down
	3		3		Ch -
	4		4		Right
	5		5		Left
	6		6		Vol -
	7		7		Vol +
	8		8		Ok
	9		9		Menu
	0		0		>>
	-/--		Guide		<<
	Recall		Back		Shift + Info
	Audio		Dual		Exit
	P.M.		Smart		Red



