



Original	Recharge
ON/OFF	Power
Freeview Play	Options
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Tv Guide	Guide
Picture	Format
Sound	Dual
Source	AV
Vol+	Vol +

Original	Recharge
Vol-	Vol -
Mute	Mute
CH+	Ch +
CH-	Ch -
Menu	Menu
Exit	Exit
Back	Back
FAV	Pre Ch
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Info	Info
Text	Text
Subtitle	Subt
TV	TV/R





Original		Recharge		Original	Recharge
	You Tube		Media		
	Netflix		Smart		
	APPS		Shift + Media		
	Rec/DVD Menu		Rec		
	I<<		I<<		
	>>I		>>I		
	Stop		Stop		
	Rec List/DVD		D. Menu		
	<<		<<		
	>>		>>		
	Play		Play		
	Pause		Pause		
	Red/Goto		Red		
	Green/A-B		Green		
	Yellow/Angle		Yellow		
	Blue/Repeat		Blue		

