





























































Original		Rechange		Original		Rechange	
	POWER		Power		6		6
	TELETEXT		Text		7		7
	Index		Play		8		8
	Clock / Subpage		Pause		9		9
	Hold		Stop		0		0
	Reveal		Rec		MUTE		Mute
	Cancel		<<		RTN.		Back
	Size		>>		CH+		Ch +
	RED		Red		CH-		Ch -
	GREEN		Green		VOL+		Vol +
	YELLOW		Yellow		VOL-		Vol -
	BLUE		Blue		ARC		Smart
	1		1		APC		Media
	2		2		UP		Up
	3		3		LEFT		Left
	4		4		OK		Ok
	5		5		RIGHT		Right





Original	Recharge
DOWN	Down
MENU	Menu
EXIT	Exit
TV	Shift + Red
PC / HD	Shift + Green
VIDEO	Shift + Yellow
SCART	Shift + Blue
SOUND	Dual
SUB-TITLE	Subt
GUIDE	Guide
SLEEP	Sleep
PIP ON/OFF	Shift + Ok
PIP SWAP	Shift + Left
PIP SWAP	Shift + Right
PIP SOURCE UP	Shift + Up
PIP SOURCE	Shift + Down
PIP SIZE	Shift + Media

Original	Recharge
PIP POSITION	Shift + Smart

