




























































































Original	Recharge
 Power	 Power
 Mute	 Mute
 More	 Smart
 Code	 Media
 Code	 Shift + Media
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Zoom	 Eject

Original	Recharge
 OPT	 Options
 Red / <<	 Red
 Green / Stop	 Green
 Yellow /	 Yellow
 Blue / >>	 Blue
 Red / <<	 <<
 Green / Stop	 Stop
 Yellow /	 Play
 Yellow /	 Pause
 Blue / <<	 >>
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 TV/Radio	 TV/R
 Rec	 Rec









































Original		Recharge		Original		Recharge	
	Back		Back				
	Info		Info				
	Prog-		Ch -				
	Prog+		Ch +				
	Vol-		Vol -				
	Vol+		Vol +				
	TXT		Text				
	Still		Shift + Pause				
	Sound		Dual				
	PIP		Format				
	Menu		Menu				
	HDMI		AV				









Original	Recharge	
PWR On/Off		Power
Mute		Mute
Epg	 + 	Shift + Guide
Opt?		Options
Subt.List		Subt
App		Media
Info	 + 	Shift + Info
Sleep Timer		Sleep
TV		TV/R
Video		D. Menu
Text		Text
Zoom		Eject
TV/SAT		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left

Original	Recharge	
OK Enter		Ok
Menu Right		Right
Exit		Exit
Menu Down		Down
Back		Back
Audio		Dual
Volume+		Vol +
CH/Page+		Ch +
Volume-		Vol -
CH/Page-		Ch -
1. ?		1
2abc		2
3def		3
4ghi		4
5jkl		5
6mno		6
7pqrm		7






















Original	Recharge	Original	Recharge
8tuv	 8	Lang./Rewind	 <<
9wxyz	 9	LNB F.Forward	 >>
Guide Pilote	 Guide		
0/10	 0		
FAV Pref.	 Pre Ch		
Red	 Red		
Green	 Green		
Dev	 List		
Home Cinema	 Smart		
West	 I<<		
Yellow	 Yellow		
Freeze	 Stop		
Blue	 Blue		
On/Off	 +  Shift + Power		
SAT Sky	 +  Shift + AV		
H/V Play	 Play		
East	 >>I		





Original	Recharge	
PWR On/Off		Power
Mute		Mute
Epg	 + 	Shift + Guide
Sleep Timer		Sleep
Opt?		Options
App		Media
Info	 + 	Shift + Info
TV		TV/R
Video		D. Menu
Text		Text
Zoom		Eject
TV/SAT		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left
OK Enter		Ok

Original	Recharge	
Menu Right		Right
Exit		Exit
Menu Down		Down
Back		Back
Audio		Dual
Volume+		Vol +
CH/Page+		Ch +
Volume-		Vol -
CH/Page-		Ch -
1. ?		1
2abc		2
3def		3
4ghi		4
5jkl		5
6mno		6
7pqrm		7
8tuv		8



