

























Original	Rechange
 Power	 Power
 Red/Setup	 Red
 Green/APP	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Home	 Smart
 Back	 Back
 I=I	 Menu
 Mouse	 Media
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 1	 1

Original	Rechange
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Mute	 Mute
 <XI	 Pre Ch

