











































































































Original		Recharge		Original		Recharge	
	Power		Power		Stop/Reveal		Stop / Hold
	Mute		Mute / Dimmer		<</Hold		<< / Tune-
	Red		Red / Netflix / Search		>>/Subpage		>> / Tune+
	Green		Green / APP / Repeat		I<</Size		I<< / Preset-
	Yellow		Yellow / YouTube / Repeat		>>I/Cancel		>>I / Preset+
	Blue		Blue / Prime Video / Random		Info		Info / Angle
	EPG		Guide / EPG / -/--		Input		AV / Input / RDS
	Home		Shift + Home / Menu /		Menu		Menu / Home
	Rec		Rec / Rec Mode		Exit		Exit / Cancel / Clear
	Setup		Setup / OPT /		Up		Up
	Sub-T		Subtitle / EQ		Down		Down
	Mouse		Smart / List		Right		Right
	T-Shift		Zoom / Size		Left		Left
	Tv/Radio		TV/Radio /		OK		OK
	Text		Text / Goto		Vol+		Vol+
	Play/Index		Play / Slow		Vol-		Vol-
	Pause/Mix		Pause / Step / Freeze		Audio		Audio / Lang I/II





Original	Recharge
 Sleep	 Sleep / Timer
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Shift + Guide / EPG / -/--
 Recall	 Back / Return
 P.Mode	 Picture / Format
 FAV	 Fav / Marker / PC

Original	Recharge
 S.Mode	 Sound / Title

