







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol+		Vol+
	Energy		Eject / Surround		FAV/Mark		Fav / Marker / PC
	AV.Mode		Zoom / Size		CH+		CH+ / Page+
	Input		AV / Input / RDS		Vol-		Vol-
	TV/Radio		TV/Radio /		3D/Char/Num		Sound / Title
	1		1		CH-		CH- / Page-
	2		2		Mute/Delete		Mute / Dimmer
	3		3		Premium		Sleep / Timer
	4		4		Home		Menu / Home
	5		5		Q.Menu/3D		D.Menu / Top
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		OK
	9		9		Right		Right
	List		Smart / List		Down		Down
	0		0		Back		Back / Return
	Q.View		Display / Media		Guide		Guide / EPG / -/-





Original	Recharge
Exit	Exit / Cancel / Clear
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Text	Text / Goto
T.OPT	Setup / OPT /
Subtitle	Subtitle / EQ
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
<<	<< / Tune-
>>	>> / Tune+
REC	Rec / Rec Mode
Info	Info / Angle
AD	Audio / Lang I/II
Ratio	Picture / Format

Original	Recharge

