




Original		Rechange		Original		Rechange	
	Power		Power		Green/Pause		Green / APP / Repeat
	Mute		Mute / Dimmer		Yellow/Sub		Yellow / YouTube / Repeat
	V+		Vol+		Blue/text		Blue / Prime Video / Random
	V-		Vol-		List		Smart / List
	Menu		Menu / Home		Tv/R		TV/Radio /
	AV		AV / Input / RDS		EPG		Guide / EPG / -/--
	Audio		Audio / Lang I/II		1		1
	Info		Info / Angle		2		2
	P+		CH+ / Page+		3		3
	P-		CH- / Page-		4		4
	Exit		Exit / Cancel / Clear		5		5
	Channel Up		Up		6		6
	Channel Down		Down		7		7
	Right/Vol+		Right		8		8
	Left/Vol-		Left		9		9
	OK		OK		0		0
	Red/RCL		Red / Netflix / Search		SAT		Shift + 0





Original	Recharge	Original	Recharge
	Zoom		Zoom / Size

